

Service Manual Outline

VI Dry Sump Stern Drive Unit

Section 1 - Important Information

- A - General Information
- B - Maintenance
- C - Troubleshooting

Section 2 - Removal and Installation

- A - Upper and Lower Drive
- B - Transom Assembly

Section 3 - Upper Drive

- A - Upper Drive

Section 4 - Lower Drive

- A - VI SSM Gear Housing

Section 5 - Transom

- A - Transom Assembly

Section 6 - Power Trim

- A - Oildyne Trim Pump

Important Information

1

Removal and Installation

2

Upper Drive

3

Lower Drive

4

Transom

5

Power Trim

6

WATERCRAFTMANUALS.COM