

# 1.8 Litre, 2.7 Litre and 3.6 Litre *OMC Sea Drive*<sup>®</sup> Hydraulic Steering Transom Bracket Assembly

Table of Contents	Page
Preface .....	2
Layout of this Book .....	3
Read Through Installation Instructions Completely .....	4
Familiarize Yourself with Parts of Transom Bracket Hardware and Tools Required .....	4
Familiarize Yourself with Transom Load Requirements .....	7
Determine Transom Angle .....	8
Lay Out Transom .....	9
Drill Transom Holes .....	14
Remove Transom Bracket From Shipping Pallet .....	16
Install Transom Bracket .....	16
Install Remote Control Cables, Speedometer Hose and Water Pressure Gauge Hose .....	18
Install Junction Box and Cables .....	20
Install Battery Cables (not supplied) .....	21
Install <i>SelectTrim/Tilt</i> <sup>™</sup> Reservoir .....	22
Install <i>VRO</i> Oil Tank .....	22
Install <i>VRO</i> Oil Hose .....	23
Install Fuel Hose .....	24
Route Control Cables Through Transom Bracket .....	24
Route Speedometer Hose and Water Pressure Gauge Hose (if used) Through Transom Bracket .....	25
Adjust for Transom Angle .....	26
Move Steering Cylinder, Cables and Hoses - Port Unit .....	27
Hydraulic Steering .....	32
Install Boat Steering System Hydraulic Lines to Transom Bracket .....	32
Fill and Bleed Steering System - Principles and General Procedures .....	34
Fill and Bleed Steering System - Single Unit .....	36
Test Steering System for Air - Single Unit .....	38
Fill and Bleed Steering System - Twin Units .....	41
Test Steering System for Air - Twin Units .....	45
Synchronize the Cylinders .....	50
Install Transom Bracket Cover and Engine Bracket Covers - All Models .....	50
Prepare for Shipping .....	50
Hose & Cable Routing and Tie Strap Location Illustration .....	57
Dimensions and Reference Drawings .....	58
Specifications .....	64
Guidelines & Recommendations .....	G-1

18HPHD, 27APPHD, 27ASPHD,  
36APPHD, 36ASPHD

Transom Bracket Assembly