

TABLE OF CONTENTS

GENERAL

INTRODUCTION	1
BRITISH SEAGULL ENGINES	2
HORSEPOWER RATING	3
ENVIRONMENT	6
HISTORY	8
MODEL IDENTIFICATION	11
FUEL:OIL RATIO	15
SPARK PLUG	17
PROPELLER SPRING	21
ENGINE OVERBOARD	22
OPERATING IN ADVERSE CONDITIONS	24
MAINTENANCE	26
ENGINE MOUNTING	29
GENERAL	31
THE BODGER FACTOR	35
SUCK, SQUEEZE, BANG AND BLOW	37
STARTING PROCEDURES	38

TROUBLE SHOOTING

GENERAL	41
IGNITION	45
CARBURETTOR	55
ODDITIES	62

REPAIRS

DISMANTLING TECHNIQUES	63
AMAL AND BING THROTTLE CONTROL LEVER	75
IGNITION	76
FLYWHEEL REMOVAL	82
RECOIL STARTER	88
CARBURETTORS	94
SQUARE CYLINDER BLOCK	109
PISTON REMOVAL AND REPLACEMENT	113
REPLACEMENT OF CRANKCASE BUSHINGS	117
WATER ROTOR and COOLING SYSTEM	119
WIDE -RATIO REDUCTION GEARBOX	124

TECHNICAL SPECIFICATIONS	131
---------------------------------	------------

ACCESSORIES AND REPAIR KITS	135
------------------------------------	------------

REFERENCES	139
-------------------	------------

MAINTENANCE LOG	140
------------------------	------------

LIST OF DIAGRAMS

Ignition	
Mark I	45
Mark II	50
Mark III	53
Carburettors	
Villiers	55
Bing	57
Amal Two-Jet	59
Amal 416	61
Recoil Starter	88
Fuel Needles and Jets	
Villiers	97
Bing	102
Amal Two-Jet	103
Amal 416	106

LIST OF MAJOR CHARTS

Model Identification	
Model Number	12
Identification	13
Fuel:Oil Mixing	16
Maintenance	28
Trouble Shooting	
Engine will not start	42
Mark I	49
Mark II	52
Mark III	54
Specifications	
Technical	131
Torque	131
Ignition	132
Throttle Valve piston Spring Length	132
Water Pump Rotor	132
Gearbox Oil Capacities	133
Propellers	133
General Specifications	134