



TABLE OF CONTENTS

SECTION 1	ENGINE COVER
SECTION 2	ALTERNATOR, IGNITION SYSTEM, ELECTRIC STARTING AND CONTROL COMPONENTS
SECTION 3	CARBURETOR, FUEL PUMP, INTAKE REED VALVES AND PUDDLE DRAIN SYSTEM
SECTION 4	POWER HEAD
SECTION 5	SUPPORT PLATE, CONTROL PANEL, STERN BRACKET, SWIVEL BRACKET & MOTOR LEG
SECTION 6	GEAR HOUSING - UPPER AND LOWER
SECTION 7	SYNCHRONIZATION OF CONTROLS
SECTION 8	SPECIAL TOOLS